

A1- Recessed mount

- Open the guard to expose the inside (hinge side) attachment section. Position the unit in the centre of the window. Install the screws.
- Pull on the release ring to free the attachment section, then install the screws, taking care to keep this attachment section even with (hinged side) attachment section.

A2- Surface mount

- Position the unit in the centre of the window, with the hinge side. Install the screws.
- Stretch out the guard until the attachment section meets the surface of your exterior frame, then install the screws.

B1- After screwing down the attachment section, stretch out the guard and engage the mechanism by pressing on it. Check the mechanism by pulling the release ring.

B2- After screwing the unit to the window frame, check the mechanism by pulling the release ring.

C- Position the plaque protecting the release ring directly under the attachment section vertically or slightly to the left or right, taking care not to create a corner that could interfere with the operation of the cable.

A1- Montage en retrait

- Ouvrir la grille pour exposer l'intérieur de la section d'attache côté charnière. Positionner l'unité au centre de la fenêtre. Procéder à l'installation des vis.
- Tirer sur l'anneau de déclenchement pour libérer la section d'attache et procéder à l'installation des vis en prenant soin de positionner cette section d'attache à égalité avec la section d'attache (avec charnière).

A2- Montage en surface

- Positionner l'unité au centre de la fenêtre, section d'attache côté charnière. Procéder à l'installation des vis.
- Étirer la grille jusqu'à ce que la section d'attache rejoigne la surface de votre cadre extérieur et procéder à l'installation des vis.

B1- Suite à l'assujettissement de votre section d'attache, étirer le grillage et enclencher le mécanisme par une simple pression. Vérifier le mécanisme en tirant l'anneau de déclenchement.

B2- Suite à l'installation des vis sur votre cadre, tirer l'anneau de déclenchement pour vérifier le mécanisme.

C- Positionner la plaque sécurisant l'anneau de déclenchement directement sous la section d'attachement à la verticale ou légèrement sur la gauche ou la droite en prenant soin de ne pas créer d'angle qui entravera le fonctionnement du câble.

